


# Eaton - Maxwell supercapacitor cross reference guide



## Eaton - Maxwell supercapacitor cross reference guide

### Small cylindrical cells and packs

Eaton	Maxwell	Eaton	Maxwell	Eaton	Maxwell
<a href="#">HV0810-2R7105-R</a>	BCAP0001 P270 T01	<a href="#">HV1030-2R7H106-1</a>	BCAP0010 P270 S12	<a href="#">TV1020-3R0605-R</a>	BCAP0005 P300 X11
<a href="#">HV0820-2R7305-AP</a>	BCAP0003 P270 S12	<a href="#">HV1625-2R7256-R</a>	BCAP0022 P270 T01	<a href="#">TV1030-3R0106-R</a>	BCAP0010 P300 X11
<a href="#">HV0820-2R7305-R</a>	BCAP0003 P270 S01		BCAP0025 P270 S01	<a href="#">TV1625-3R0256-R</a>	BCAP0025 P300 X11
	BCAP0003 P270 T01		BCAP0025 P270 T01		
<a href="#">HV1020-2R7505-R</a>	BCAP0003 P270 X01	<a href="#">HV1840-2R7606-R</a>	BCAP0050 P270 S01	<a href="#">TV1840-3R0606-R</a>	BCAP0050 P300 X11
	BCAP0005 P270 T01		BCAP0050 P270 T01	<a href="#">PHB-5R0V155-R</a>	BMOD0001 P005 B02
<a href="#">HV1030-2R7106-R</a>	BCAP0005 P270 X01	<a href="#">HV1860-2R7107-R</a>	BCAP0100 P270 S07	<a href="#">PHB-5R0V255-R</a>	BMOD0002 P005 B02
	BCAP0010 P270 T01		BCAP0100 P270 T01		
BCAP0010 P270 X01	BCAP0100 P270 T07				

Cross references shown may differ in electrical properties and performance characteristics. Eaton recommends that customers review our suggestions and make the final selection based upon individual requirements. This list is for reference only. Eaton is not responsible for misapplications of our products.



Powering Business Worldwide

# Eaton - Maxwell supercapacitor cross reference guide

## Large cell and module supercapacitor

Eaton	Maxwell (EOL part number)	Eaton	Maxwell (EOL part number)	Eaton	Maxwell (EOL part number)
<a href="#">XV3550-2R7307-R</a>	BCAP0310 P270 T10	<a href="#">XL60-2R9348T-R</a>	BCAP3400 P285 K04	<a href="#">XLR-48R6167-R</a>	BMOD0165 P048 B01 BMOD0165 P048 B06 BMOD0165 P048 B09 BMOD0165 P048 C01
<a href="#">XV3585-2R7607-R</a>	BCAP0650 P270 K04 BCAP0650 P270 K05	<a href="#">XL60-2R9348W-R</a>	BCAP3400 P285 K05	<a href="#">XLR-16R2507B-R</a>	BMOD0500 P016 B01 BMOD0500 P016 B02
<a href="#">XV3560-2R7407-R</a>	BCAP0325 P270 S17 BCAP0350 E270 T11 BCAP0350 E270 T13 BCAP0350 P270 T11 BCAP0350 P270 T13 BCAP0360 P270 S18	<a href="#">XL60-2R7308T-R</a>	BCAP3000 P270 K04		
<a href="#">XVM-16R2656-R</a>	BMOD00058 E016 B01 BMOD00058 E016 B01 BMOD00058 E016 B02	<a href="#">XL60-2R7308W-R</a>	BCAP3000 P270 K05		
		<a href="#">XLM-62R1137A-R</a>	BMOD0130 P056 B03		

Cross references shown may differ in electrical properties and performance characteristics. Eaton recommends that customers review our suggestions and make the final selection based upon individual requirements. This list is for reference only. Eaton is not responsible for misapplications of our products.

**Eaton**  
**Electronics Division**  
 1000 Eaton Boulevard  
 Cleveland, OH 44122  
 United States  
[Eaton.com/electronics](http://Eaton.com/electronics)

© 2023 Eaton  
 All Rights Reserved  
 Printed in USA  
 Publication No. 11242  
 June 2023

Eaton is a registered trademark.

All other trademarks are property of their respective owners.